

LED Dimmer Installation

- 1) Connect dash light power (usually from the existing vehicle dimmer switch) to the outer position of the dimmer's terminal strip labeled "Dash Light Power".
- 2) Connect a good ground to the middle position of the dimmer's terminal strip labeled "Ground".
- 3) Connect the gauge's LED dash light power wire to the inner position of the dimmer's terminal strip labeled "To Gauge".

Note: Dimmer is only designed to provide power to Classic Instruments LED dash lights. Connecting incandescent bulbs or other LEDs may overload the dimmer and cause damage.

